
F200

Neolce

Handheld Fan

User Manual

Production introduction



Attention:
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device nay not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Instructions for use

Display:

1. When the fan is charging, the display shows the battery percentage. The % icon flashes while charging. The display will show 100% when charging is complete.
2. When the battery level is below 5%, the display screen flashes.
3. The power level is displayed during use; the battery level is displayed for 2 seconds when the device is turned on or off.
4. When charging and using simultaneously, the display shows the charging level, with the percentage indicator flashing.

Speed control knob:

+ : Clockwise rotation increases wind speed.
—: Counterclockwise rotation reduces wind speed.

Cooling button:


A short press turns the cooling on/off; the cooling icon will light up when activated(Note: This function only available when then fan is on.)

Power button:

Long press to turn on, long press to turn off, double-tap to check battery level.

Product parameters

Product Model: F200
Product name: Neolce Handheld Fan
Rated input: 5V⎓2A
Charging input: 5V⎓2A
Battery capacity: 5000 mAh(18.5Wh/3.7V)
Product weight: 7.19 oz
Product size: 7,52×1,44×2,89 in



Note:

The battery must be removed before disposing of the appliance;
The appliance must be powered off when the battery is removed;
Batteries should be disposed of safely.

Steps to remove the battery:

1. Pry off the back cover.
2. Remove the battery holder from the mainboard and take out the battery.

Attention

1. This product uses lithium batteries and has no memory function. Overcharging and over-discharging will affect the life of the product. Please charge in time and disconnect from power promptly after the device is fully charged.
2. When the fan is on, the blades rotate at a high speed. Do not put your fingers into the fan to avoid harm.
3. This product is not a children' s toy. Children under 10 years of age should use the fan only with adult supervision.
4. Please use the adapter that meets the national standard to power on,and the power is above 1A.

Warranty

The Company warrants, to the original purchaser only, this product to be free from defects in workmanship and materials under normal use and service (all except human matters) for 1 year from the date of receiving.

Customer Service : airdogint@gmail.com

Official Website : www.airdogint.com

Address(China) : Building 1, NO. 175 Songbei Road, Suzhou Industrial Park, Suzhou, Jiangsu, China

Address(USA) : AirdogUSA Service Center 1611 W. SAN Bernardino rd, unit 10, West Covina, CA 91790

Scan QR code for more Video Instructions (Airdog Youtube channels)

Please Recycle

说明书

书纸 100g 折叠